

Index →

Installation 、 Configuration Process - 1
Interface setting - 2
Trigger Mode/ LED Flash Mode - 4
Barcode Setting - 5
Testing Chart, RS232 PIN Assignment- 7
Barcode Setting, Code 39 Parameters - 8

Barcode Scanner Quick Manual



9 - Code 39, UPC/EAN Add 2/5 Code Parameters 、 Code 93 Parameters
10 - EAN-13 、 UPC Code Parameters
11 - ISBN/ISSN/ 、 CodeMark I.D. 、 CodeMark Appendix
12 - Code 128 /EAN-8/China Postage Parameters
13 - UPC-A 、 UPC-E Code Parameters
14 - Codabar Code Parameters
15 - Interleave 2 of 5 / Matrix 2 of 5 Code Parameters

← Index

Installation 、 Configuration Process - 1

The CCD scanner can be easily interfaced to a keyboard or a serial port to your computer. Now follow the procedures below for a proper installation.

To install the scanner as keyboard wedge:

On your first time installation, it is necessary to select a compatible computer type. (See the configuration manual for the correct type.)

- 1) Plug the phone jack of scanner cable into your CCD scanner.
- 2) Turn off your computer.
- 3) Remove the keyboard plug from our computer, plug it into the Din-5P or PS/2 female connector of scanner cable, and then connect the Din-5P or PS/2 make connector to the keyboard port of your computer.
- 4) Turn on the power of computer, the red LED indicator will light and the CCD scanner will beep to indicate a correct installation.

To install the scanner as a RS-232C device:

- 1) Plug the phone jack of scanner cable into your CCD scanner.
- 2) Turn off your computer.
- 3) Plug the DB-9P female connector of serial cable into RS-232C port on your computer.
- 4) If it is necessary, plug another end of DC jack to the adapter.
- 5) Turn on the power of computer, the red LED indicator will light and the CCD scanner will beep to indicate a correct installation.

Configuration Process

One or more parameters can be re-configured to fit your need. The basic three steps of custom configuration are:


- 1) Scan " START " label
- 2) Scan desired parameters
- 3) Scan " END " label

You can also refer to the flow chart shown on the back of the front cover for a better idea of the configuration process.


Important configuration commands are as under:

- START - to begin custom configuration procedures.
END - to end the configuration procedures and save the new selected parameters.
SET - to give up the new settings and return to the defaults.


PS2 / USB interface-2







RS-232 Interface -3




Trigger Mode \ LED Flash Mode - 4

START 

Trigger Mode

*** Normal Reading Mode:**
Trigger on/off
 Continuous/no-trigger

 Continuous/trigger off
 Trigger on/good read off


END 


Normal Reading Mode: Trigger on/off Pushing the keytop, the LED is keeping on. Off the keytop or while the scanner has a good read, the LED is off. When the LED is off by losing the keytop, the LED will be On again while we pushing the keytop again and ready to read decoding code.

Continuous/No trigger LED is always on. The barcode put in front of scanner only decode once. Change another barcode will decode another time. If you want to re-scan the same barcode, you have to move the barcode away and put it in front of the scanner window side, will do the second decode.

Continuous/trigger off LED is turned on by pressing the trigger, when the barcode put in front of the scanner will decode, but only decode once, won't read continuously. The read mode will be the same like Mode 2. And when you pressing the trigger again, the LED will off and won't read the code again. And press the 3rd time, the light will be ON again will repeat the decode again.

Trigger on/good read off Connect the power, pushing the trigger, and LED will be ON 5 sec continuously, if there is no decoding during these 5 sec the LED will be off. And during this 5 sec while the scanner read successfully, the LED will be off as well.


LED FLASH Mode



START 



LED flash Enable
 *LED flash DISABLE




END 


Barcode Setting -5



START 


UPC - A Code
 * ON  OFF 


UPC - E Code
 * ON  OFF 

EAN - 13 Code
 * ON  OFF 


EAN - 8 Code
 * ON  OFF 

Code - 39 Code
 * ON  OFF 



Codabar Code
 * ON  OFF 

END 



Barcode Setting-6

START 



Code 93 code

* ON  OFF 



Code 128 code

* ON  OFF 



Interleaved 2 of 5 Code

ON  *OFF 



Industrial 2 of 5 Code


ON  *OFF 

Standard 2 of 5 code

ON  * OFF 


Matrix 2 of 5 Code


ON  *OFF 


END 


Testing chart - 7


These barcodes for let you test see if the barcode setting open already.


UPC-A 
0 04454 52462 4


UPC-E 
0 783491 8


EAN-8 
2468 1353


EAN-13 
9 787506 631266
(ISBN 7-5066-3126-1)

Code 39 
CCD80S

Code 93 
12345

CODABAR 
389193724


Code 128 
TW00886228801618

Interleaved 2 of 5 
1094097514


RS232 PIN ASSIGNMENT

DUSB-9P Female


- 1 — N/C (=no connection)
- 2 — TXD
- 5 — GND
- 7 — CTS
- 8 — RTS
- 9 — VCC (+5V)



DC Adapter
+5v +- 10%
150mA (min.)




SET to scanner default




A01

Barcode Setting 、 Code 39 Parameters -8




Code 39 Parameters




Code 93 Parameters 、 UPC/EAN Add 2/5 code -9


Code 39



Code 93




UPC/EAN Add 2/5 code





EAN-13、UPC Code Parameters -10

UPC code & EAN code transfer


START 


* UPC-A NOT Transfer to EAN-13


 UPC-A transfer to EAN-13




* UPC-E NOT Transfer to UPC-A


 UPC-E Transfer to UPC-A



END 


EAN-13 Code


START 


ex 
1 2 3 4 5 6 7 8 9 1 2 3 1
(for example, not setting)

check digit

* Transmitted Check Digit

 NOT Transmitted



END 


ISBN/ISSN/ Parameters \ CodeMark I.D.-11

EAN-13=ISBN/ISSN Code?




EAN-8/China Postage Parameters -12


EAN-8 Check digit



CodeMark I.D. setting (see the CodeMark Appendix at below)




ChinaPostage Code




UPC-A \ UPC-E Code Parameters -13

UPC-A Code




UPC-E Code




Codabar Code Parameters -14

Codabar Code



Interleave 2 of 5 / Matrix 2 of 5 Code Parameters -15

Interleaved 2 of 5 Code



Matrix 2 of 5 Code

