

文字間ディレイ設定

1. 設定の開始



2. 使用するモードを選択

B> 文字間ディレイ

設定コード	説明	設定コード	説明
 %0070	〈なし〉 (デフォルト)	 %0074	50 ms
 %0071	5 ms	 %0075	100 ms
 %0072	10 ms	 %0076	200 ms
 %0073	25 ms	 %0077	300 ms



3. 設定の終了



4. 設定を保存

